

## Zasilacz 16V 4.5A do Notebooka Qoltec 7315



**Cena : 59,90 zł**

Nr katalogowy : **8288**

Stan magazynowy : **brak w magazynie**

Średnia ocena : **brak recenzji**

**Przeznaczenie:** sieciowy

**Napięcie wyjściowe:** 16 V

**Prąd wyjściowy (maks.):** 4 A

**Moc zasilacza:** 72 W

**Wtyczka:** 5.5\*2.5

### Pasuje do:

**IBM ThinkPad:** 130, 235, 240, 240X, 240Z, 390, 340, 345, 360, 370, 380, 365, 365C, 365CD, 365CS, 365CSD, 365E, 365ED, 365X, 365XD, 380, 380D, 380E, 380ED, 380XD, 380Z, 385, 385CD, 385D, 385ED, 385XD, 390X, 535, 550, 560, 560C, 560E, 560X, 560Z, 570, 570E, 600, 600E, 600X, 701, 701C, 701CS, 770, 770E, 770ED, 770X, 770Z

**IBM ThinkPad A Series:** A20, A20, A20M, A20P, A21, A21E, A21M, A21P, A22E, A22M, A22P, A30, A30P, A31, A31P

**IBM ThinkPad E Series:** E530

**IBM ThinkPad i Series:** i-1200, i-1210, i-1211, i-1241, i-1251, i-1271, i-1300, i-1321, i-1340, i-1351, i-1351, i-1391, i-1418, i-1420, i-1421, 1441, i-1442, 1460, 1480, i-1482, i-1500, i-1700, i-1720, i-1721, i-1351, i-1361, i-1391

**IBM ThinkPad R series:** R30, R31, R32, R40, R40E, R50, R50E, R50P, R51, R52

**IBM ThinkPad T Series:** T20, T21, T22, T23, T30, T40, T40P, T41, T41P, T42, T42P, T43

**IBM ThinkPad X Series:** X20, X21, X22, X23, X24, X30, X31, X40, X41

**Panasonic CF CF-1 Series:** CF-18

**Panasonic CF CF-R Series:** CF-R1

**Panasonic CF CF-R4 Series:** CF-R4, CF-R4GC5AXS, CF-R4GW5AXR, CF-R4GW5AXS, CF-R4GWCKZBR, CF-R4GWCZBR, CF-R4HC4AXS, CF-R4HW4AXR, CF-R4HW4AXS, CF-R4JC4AXS, CF-R4JW4AXR, CF-R4JW4AXS, CF-R5

**Panasonic CF CF-R5 Series:** CF-R5KC4AXS, CF-R5KW4AXP, CF-R5KW4AXR, CF-R5KW4AXS, CF-R5KWPAXP, CF-R5LW4AXR

**Panasonic CF CF-W2 Series:** CF-W2, CF-W2AW1AXR, CF-W2BW1AXR, CF-W2BW1HXR, CF-W2CW1AXR, CF-W2DW1AXR, CF-W2DW6AXR, CF-W2DWAZZKM, CF-W2EW1AXR, CF-W2EW6AXR, CF-W2FW6AXR, CF-W2FWCFZBM-EC, CF-W2FWCZBZBM

**Panasonic CF CF-W4 Series:** CF-W4, CF-W4GC5AXS, CF-W4GW5AXS, CF-W4GW9AXR, CF-W4GW9AXS, CF-W4GW9HXR, CF-W4GWCZBM-EC, CF-W4GWCZBZBM, CF-W4GWCZBR, CF-W4HW8AXR, CF-W4HW8HXR, CF-W4HWEZBZBM, CF-W4HWEZBR

**Panasonic CF CF-Y2 Series:** CF-Y2, CF-Y2CW4AXR, CF-Y2DW1AXR, CF-Y2DWAZZKM, CF-Y2EW1AXR, CF-Y2EW6AXR, CF-Y2FW7AXR, CF-Y2FW7HXR, CF-Y2FW7PZZBM-EC

**Panasonic CF CF-Y5 Series:** CF-Y5, CF-Y5KC2AXS, CF-Y5KW2AXS, CF-Y5KW4AXS, CF-Y5KW8AXR, CF-Y5KW8AXS, CF-Y5KWSAXP, CF-Y5KWYAXP, CF-Y5LC2AXS, CF-Y5LW2AXS, CF-Y5LW4AXS, CF-Y5LW8AXR, CF-Y5LW8AXS, CF-Y5MC2AJS, CF-Y5MC2AXS, CF-Y5MW2AJS, CF-Y5MW2AXS, CF-Y5MW4AJS, CF-Y5MW4AXS, CF-Y5MW8AJR, CF-Y5MW8AJS, CF-Y5MW8AXS

**Panasonic ToughBook W Series:** W2, W4

**Panasonic ToughBook Y Series:** Y2, Y5